

# CONCORD



CEAUSBCMVA

## **USB-C Stereo Earphones**

**User Manual**

**AA2148**

## Contents:

- 1 x USB-C Earphones
- 1 x Large Ear Tips
- 1 x Medium Ear Tips (Included On Earphones)
- 1 x Small Ear Tips



## Product Diagram:

1. Ear Tips
2. Cable Strain Relief
3. Internal Speaker
4. USB Type-C Connector
5. Volume Up
6. Play/Pause/Call/Hang Up/Next Track/  
Previous Track/Voice Assist
7. Volume Down
8. Cable

| <b>Function</b>             | <b>Button</b>  |
|-----------------------------|--|
| <b>Play</b>                 | Press the play/pause/call/hang up button again after pausing to resume the current music track |
| <b>Pause</b>                | Press the play/pause/call/hang up button to pause the current music track                      |
| <b>Increase Volume</b>      | Press and the volume up/next track button to increase the volume                               |
| <b>Decrease Volume</b>      | Press the volume down/previous track button to decrease the volume                             |
| <b>Next Track</b>           | Press the play/pause/call/hang up button twice to skip to the next music track                 |
| <b>Previous Track</b>       | Press the play/pause/call/hang up button three times to skip to the next music track           |
| <b>Answer Incoming Call</b> | Press the play/pause/call/hang up button   |

|                             |   |
|-----------------------------|---|
| <b>Reject Incoming Call</b> | Press and hold the play/pause/call/hang up button for up to 2 seconds to reject the current incoming call   |
| <b>Hang Up Call</b>         | Once a call has been recieved; press and hold the play/pause/call/hang up button  |
| <b>Voice Assist</b>         | Press and hold the play/pause/call/hang up button for up to 2 seconds to bring up Google Assist on your smart phone. This may depend on your smartphone type. |

## **Compatibility:**

The microphone and volume control is not suitable on all devices. Refer to manufacturers website or user manual of your device prior to use to see if these functions can be supported.

## Specifications:

|                     |            |
|---------------------|------------|
| Driver Size:        | 10mm       |
| Frequency Response: | 20Hz-20KHz |
| Sensitivity:        | 98dB+-     |
| Mic Sensitivity:    | -42dB+-3dB |
| Impedance:          | 16Ω        |
| Connector:          | USB Type-C |
| Cable Length:       | 1.2m       |

## Warranty Information:

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months. If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose. This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure. To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim. Any expenses relating to the return of your product to the store will normally have to be paid by you. The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by: Electus Distribution  
Address 46 Eastern Creek Drive, Eastern Creek NSW 2766  
Ph. 1300 738 555